

## Instructions *You should enable “game mode” on your tv and/or home theater system to prevent input lag issues.*

First plug in the 2 usb controllers

Next, plug in the hdmi cable to the tv/home entertainment system and the game console.

Finally plug the micro usb power supply in. **Power supply should be plugged in directly to the wall and not a power strip.**

Hit the power button on the cable and it will boot up.

### Menu Navigation

Use the gamepad arrows to navigate to the system you want to play and then press (A).

Use the gamepad arrows to scroll down the game list. For fast scrolling use the right shoulder button (R) on top of the game controller to go down and the left shoulder button (L) to go up.

Press (A) to select the game. Don't hit any buttons while it's loading (grey box showing) To go back press (B).

To quit a game press (select) and (start) at the same time.

To save a game state press (select)(R) while in the game.

To load a game state press (select) (L) while in the game.

For Arcade games use the SELECT button to insert quarters.

### Shutdown (very important)

You must properly shutdown the system or you risk damaging the memory card just pulling the plug. Simply exit the game to the main menu, press (start) to

bring up the shutdown menu and scroll to the bottom and select “quit” and then “shutdown system” and then “yes”.

To start the system back up push the power button on the power supply cable.

### Activate game cheats

(doesn't work with all systems or games)

While in the game you are playing hit (select) and (x)

Select the “quick menu” by hitting (A)

Select “cheats” (A)

Select “load cheat file” (A)

Select system you are playing currently (A)

Select the game cheat file you want to try (A)

*\*warning\* make sure you are choosing the same exact edition of the game you are playing or it won't apply the cheats to the correct one.\*\**

Select the cheat you wish to activate using the side arrows to turn it on/off

*\*warning\* some cheats may have unexpected results so some trial and error may be required depending on the game and cheat.*

Scroll up and select “apply cheat changes” (A)

Hit (B) to go back

Select “save game overrides” (A)

Select resume (A) to try it

If you don't like how the cheat is performing you can perform the above steps to try another or turn it off.

*If you have any questions, shoot us an email and we'll be happy to assist you in any way possible [customerservice@gameboxhero](mailto:customerservice@gameboxhero).*